


# Grex CR45

## 1-3/4" Length Coil Roofing Nailer

# EXPLODED DIAGRAM



# Grex CR45

## 1-3/4" Length Coil Roofing Nailer

# PARTS LIST

Part No.	Description
15001	Seal
15003	Spring
15010	Trigger Valve Head
15011	Trigger Valve
15012	Spring
15013	Trigger Valve Guide
15021	Cap Gasket
15022	Bottom Gasket
15023	Inlet Cap Gasket
15400	Deflector
15410	Cap
15440	Trigger Valve Stem
15453	Primary Trigger
15470	Secondary Trigger
15480	Gun Body
15510	End Cap
15600	Safety Guide
15660	C-Ring
15773	Standard Trigger Assembly
15870	Seal
15880	Seal
26590	Bunper
31030	Nose Piece
31040	Feed Pawl
31050	Piston
31060	Door
31070	Retainer
31080	Door Cover
31090	Spring
31100	Guide Lock
31110	Button
31120	Spring
31130	Cap
31140	Spring
31150	Magazine
31160	Cover
31170	Seal
31180	Plate
31190	Cover
31200	Guide
31210	Adjust Post
31220	Guide
31230	Plate
31270	Spring
31280	Cover
31290	Body Guard

Part No.	Description
31300	Magnet
31310	Pin
31320	Spring
31330	Pin
31340	Pin
31350	Pin
31360	Piston Ram Assembly
31390	Magazine Assembly
31401	Safety A Assembly
31410	Retainer
31420	Spring
35181	Piston O-Ring
35190	Cylinder
35200	Cylinder Spacer
35500	Head Valve Assembly
85001	Self Drilling Screw
86001	C-Ring
88006	Hex. Soc. Head Screw
88008	Hex. Soc. Head Screw
90001	Hex. Soc. Head Set Screw
92002	Lock Nut
92004	Lock Nut
93004	Spring Pin
93005	Spring Pin
93008	Spring Pin
94001	Coupling Plug
96005	O-Ring
96010	O-Ring
96011	O-Ring
96012	O-Ring
96013	O-Ring
96014	O-Ring
96015	O-Ring
96018	O-Ring
96020	O-Ring
96028	O-Ring
96051	O-Ring
96052	O-Ring
97002	Spring Washer
97003	Spring Washer
99006	Hex. Soc. Head Screw
99014	Hex. Soc. Head Screw
99015	Hex. Soc. Head Screw
99037	Hex. Soc. Head Screw
99041	Hex. Soc. Head Screw